



BIO-DRY® ASPHALT CONDITIONER APPLICATION INSTRUCTIONS

TOOLS

- **Wire Brush with Scraper** – Contact Representative
- **Blower** (*optional for excessive debris in the area or a waste container may be used*)
- **Dust mask** – *Although Bio-Dry® contains natural ingredients, we recommend wearing dust masks to reduce inhalation of the powder and other debris.*

APPLICATION PROCESS

- Scrape any standing gum or other debris on affected area using heavy wire brush or scraper.
- Remove any heavy condensation or water with blower or soak it up with rags.
- Scrape up excess build up on heavy oil spill areas.
- Use wire brush on the remaining heavy oil spots with a small amount of Bio-Dry® and remove residue and dispose appropriately. Because water is not used it is important to wire brush any standing mud or dirt build up throughout the area.
- Remove any debris around the area to be cleaned. Either by sweeping or using a blower.
- Spread Bio-Dry® down the center of the area.
- Sweep Bio-Dry® from side to side then up and down the area to ensure coverage to the entire area. Sweep any excess Bio-Dry® into the oil stains as needed. The oil will begin to break down. Any excess Bio-Dry® left on these areas will ensure that the stains will continue to be treated after the application.
- Repeat weekly or as spots begin to show through as needed.

IMPORTANT

Do not blow or wash off the excess product. Bio-Dry® is designed to be left on the affected area so it continues to work after cleaning. Retreat areas as necessary. With regular routine Bio-Dry® maintenance the oil and grease stains will minimize and eventually disappear.

NOTE: Because Bio-Dry® is designed for high traffic grease and oil situations and these instructions have been tailored for that specific purpose. Slight alterations might be necessary for other applications.

Bio-Dry Products, LLC
PO Box 10318 • Wilmington, NC • 28404 • USA
Office 1-910-254-7690 • Fax 1-888-878-9760